



M TEAM
www.mvteamcctv.com

Fingerprint Smart Door Lock



- 1- 360° 全方位旋轉鎖體
- 2- FPC 360° 旋轉鎖體
- 3- C 型鎖體 3 個鎖點
- 4- 4 個鎖點
- 5- 4 個鎖點 12mm & 180000 轉
- 6- USB 充電
- 7- 防盜/防撬



000	C7-ZKM
-----	---------------



Fingerprint



Password



Card



Key





Battery Case

Indoor Handle



Fingerprint sensor

Card sensor area

Password keyboard

Outdoor Handle



Free-Style Handle
Drop-down(open)/Drop-up(lock)

USB charging interface

Hidden keyhole

Bio-semiconductor Fingerprints

Bank-specific fingerprint
recognition, only recognize
living fingerprint.



Speed
0.3S

Multi-Color Selection



Titanium gray



Silver




Gold




Red bronze

Lock Panel Size



Lock Mortise Size



Unit: mm



Power Supply

4 x AA(5 alkaline) batteries,
6 months & 180000 times using.

USB Charge

With backup USB port for
emergency charging.



Warmly notice:

Due to international shipping problem, we will not deliver batteries come with locks.
Please buy 4 section 5-Alkaline batteries by yourself from local market.

Package & Accessories



Door Opening Direction



Left Handle



Right handle

Matters needing attention:

There are 4 door types as below drawing showing, Please let us know:

- 1.what types of the doors?
- 2.how many quantity per each type?



A

Left Handle (push)



B

Right Handle (Push)



C

Left Handle (pull)



D

Right Handle (Pull)

A: left handle push the door to enter the room.

B: left handle pull the door to enter room.

C: right handle push the door to enter the room.

D: right handle pull the door to enter the room.

Are there heaven and earth hook of the door?



How to check?

1. Touch the top edge of the door to check if there are lock holes.
2. When the door lock is in pop up status, check whether there are lock tongues pops out on the top edge of the door.

With bolt No bolt

